/	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00	2-00-00
	GE	11	11	11			11		[]	[]	CT1LAS	CT1 LAS	CT1 LAS	CT1 LAS	CT1 LAS	CT1 LAS			11	11	11	11	Γ1
	CT1	IJ	IJ	<u>D</u>	U U	Ū	Ū	U U	С О	U U	CT1	CT1	CT1	CT1	CT1	CT1	CT1	D	<u>D</u>	Ū	U U	U U	Ü
													9	*		¥							
				V	₩	₩	V		V	V V	V	V V	V	V	V V	V V	₩		V		V	V .	
	1	11	11	11	11	11		11	11	11	11		52 0					11	11		11		1
/	/		52-00-00																				

FIELD BRACING IS NOT THE RESPONSIBILITY OF THE TRUSS FABRICATOR, TRUSS DESIGNER, OR PLATE MANUFACTURER. PERSONS ERECTING TRUSSES ARE CAUTIONED TO SEEK PROFESSIONAL ADVICE REGARDING TEMPORARY AND ERECTION BRACING WHICH MAY BE REQUIRED IN SPECIFIC APPLICATIONS. TRUSSES SHALL BE ERECTED AND FASTENED IN A STRAIGHT AND PLUMB POSTION. REFER TO THE ENGINEERED TRUSS DRAWINGS FOR SHEATHING/PURLIN SPACING REQUIREMENTS FOR TOP AND BOTTOM CHORDS. TRUSSES MUST BE HANDLED WITH EXTREME CARE TO PREVENT DAMAGE OR PERSONAL INJURY. REFER TO TRUSS ENGINEERED DRAWINGS FOR CONNECTION AND BRACING REQUIREMENTS. THESE CALCULATIONS ARE SUPPLIED IN ORDER FOR THE ENGINEER OF RECORD TO ADEQUATELY DESIGN FOR THE CONNECTION OF THE ROOF ASSEMBLY TO THE SUPPORTING STRUCTURE. CONTACT TRUSS MANUFACTURER WITH ANY QUESTIONS CONCERNING TRUSS PLACEMENT.

28-00-00

52-00-00

